



DTS

SLIDING GATE MOTOR INSTALLATION MANUAL



DTS 500 Expert

DTS SECURITY

P.O.BOX 3399

EDENVALE


1610

TELEPHONE 086 1000 387

Spartan	+2711 392 5540 (H/O)
Pretoria	+2712 361 5528
Alberton	+2711 907 8846
Natal	+2731 916 4002

www.dtssecurity.co.za

BASE PLATE MOUNTING INSTRUCTIONS (FOR ALL MODELS)



1. Assemble base plate by fastening M10x30 Hex set screws into base plate from under the base plate up and tightening into position.
2. Mount base plate with bolts 160mm from the centre of the gate track and centre of base plate a minimum of 250mm away from the gate opening.
3. Secure the base plate to the gate track by welding the base plate directly to the gate track. (Ensuring a distance of 160mm from centre of gate track to centre of fastening screws).
4. Fit all required cabling through hole provided in base plate.
5. Support the back of the base plate with 40x40x3 angle iron (not provided) or similar off cut steel knocked approximately 300 to 400mm into the ground.
6. Fill area below and around the base plate with approximately 300x400x300 concrete to ensure that the motor will be secure.
7. **NOTE** – For **SAFETY** reasons, **ALL** motors should be fitted with a set of IR beams.

Note:


When connecting intercoms to the control card (IT and CMN), please ensure that your intercom trigger output is potential free (**ZERO voltage**). If not, a gate relay module **must** be fitted.

Gearbox mounting instructions (All models)

1. Fit gearbox over mounting bolts protruding from base plate.
2. Slide gate fully open and closed, insuring pinion gear has approximately 5mm clearance to gate at all times.
3. Fasten gearbox down firmly to base plate using M10 washers and nuts.

How to override the gate motor for manual operation

1. Unlock and open the override lever on the gearbox.




2. The gate can now be opened and closed manually.

Rack mounting instructions

1. Unlock and open manual override lever fully to disengage gearbox. (See above).
2. Using a 2.5 to 3mm spacer between the pinion gear and the rack, mount the rack using Tek screws No12x20 (not provided) and screw the rack to the gate starting from the tail of the gate and ensuring that the rack is mounted level.
(A 2.5 to 3mm spacer can also be put between motor and base plate when fitting rack. This must be removed once the rack is in place).


NB: Ensure that one of the screws attaching the nylon rack to the angle is in line with the read switch or limit switch spring when the gate is fully closed and open position.




Limit switch actuator mounting instructions

1. Remove the screw attaching the nylon rack to the angle that is closest to the position of the reed switch or the spring on the motor when the gate is in the close and open position.
2. Fit limit switch actuators with screws provided onto the nylon rack.
3. Setting the gate close actuator – Close the gate with approximately 15-20mm gap between gate and close stopper. Now move the actuator until the close LED lights up. Fasten the actuator.
4. Setting the gate open actuator – Open the gate with approximately 15-20mm gap between gate and open stopper. Now move the actuator until the open LED lights up. Fasten the actuator.
5. **The gate must never bump against the close or open end stoppers.**

Magnetic limit actuator



Spring limit actuator



Important: For safety reasons, a solid stop must be fitted at **both ends** of the gate to prevent the gate from moving past its full open or close position.

ON BOARD RECEIVER PROGRAMMING

The onboard receiver is designed to work with most rolling code transmitters.
(The override lever must be closed for programming transmitters).



PROGRAMMING A TRANSMITTER (TX) FOR FULL OPEN OPERATION – GATE (Version 1.3)	PROGRAMMING A TRANSMITTER FOR PEDESTRIAN OPERATION – PED (Version 1.3)
<ol style="list-style-type: none"> 1. Push the GATE button, the RX led will go on. 2. Push the required button on the transmitter, at arm's length from PCB once, the Rx led will flash. Press the same button again, and the PCB will emit 3 beeps for a full Keelog transmitter or 2 beeps for other transmitters. 3. Repeat Step 1 and 2 for additional transmitters. Up to 31 transmitters (Slots) can be programmed as a joint combination between GATE & PED. 	<ol style="list-style-type: none"> 1. Push the PED button, the RX led will go on. 2. Push the required button on the transmitter, at arm's length from PCB once, the Rx led will flash. Press the same button again, and the PCB will emit 3 beeps for a full Keelog transmitter or 2 beeps for other transmitters. 3. Repeat Step 1 and 2 for additional transmitters. Up to 31 transmitters (Slots) can be programmed as a joint combination between GATE & PED.

The TX button used for GATE cannot be used for PED and vice versa.

To individually erase transmitters:

To erase a button from the receiver, in case of incorrect programming i.e. blue button should be for GATE and not PED. Simply push and hold the GATE button for 5 seconds, the board will give 1 beep. Release the GATE button. Then push and release the TX button you want to erase, the PCB will beep twice as confirmation. The TX is erased and can be learned into correct input.

To master erase:

Push and hold the GATE button, after 5 seconds the board will give 1 x 1 second beep. Keep holding for another 5 – 10 seconds then the board will give 1 x 2 second beep (Older version PCB's will give 2 beeps). Release GATE button. The green receiver (RX) led will also flash 5 times indicating all transmitters erased.

Note: When programming TX no.32, the PCB will give 1x 1.5second beep after pressing and releasing the GATE button indicating, Receiver (RX) is full.

The RX will abort programming automatically.

A TX must then be deleted before a next TX can be programmed to the RX.

If a transmitter is already programmed, the RX LED will go off with no beep on the 1st press from the TX.

To change the receiver from Open to Full Keelog mode and Visa Versa

Push and hold the GATE button, while holding the GATE press and hold the PED button. Keep holding both buttons for the same period of time as for the Master Erase procedure. 5 flashes will confirm Open code and 10 flashes will confirm Full Keelog. On release of both buttons the procedure is completed.

(Please note that with Full Keelog, **ONLY** the DTS TX4 with the blue buttons can now be used).

List of LED indications.

- LED ON when open limit is activated. (gate open).
- LED OFF when close limit is activated. (gate closed).
- LED flashing SLOW (1 sec. on/1 sec. off) (gate is in motion).
- LED flashes 2 long/3 short continuously (gate is stopped midway).
- LED flashes fast (250ms on/250ms off) continuously. (gate in overload).
- LED flashes 3 fast flashes every 1.5 seconds. (Battery low, <11VDC).
- LED flashes 1 slow/2 fast continuously. (NO 220 VAC power present).

DTS 500 Expert

ELECTRONICS

FEATURES:

- 1) Standard mode.
- 2) Easy motor direction change.
- 3) Auto close facility. (Infra-red beams must be fitted if auto close is activated).
- 3a.) Party mode. (Auto close override)
- 4) Condominium / Free exit loop facility.
- 5) P.I.R.A.C. (Passive Infra-Red Access Control) facility.
- 6) Slowdown (Ramp down) facility.
- 7) Tamper alarm facility.
- 8) Anti-hijack.
- 9) Holiday Lockout.
- 10) Energy saving mode (Standard)

1. Standard Mode. (No function selected).

When the gate is activated it will open and can be stopped in mid cycle by pressing the transmitter or manual push button. Pressing the transmitter or push button can reverse the gate. In standard mode the gate will remain on its open limit until it is triggered to close. If main power fails, the motor will still operate until battery reaches 9.5 volt. Gate will then remain close (Open if condominium mode is selected). Change to manual by overriding the motor by the override lever. When the main power comes on again, lock in the override lever and the motor will function as normal.

2. Easy motor direction change. (Dipswitch 2).

By selecting the dipswitch, the motor direction and the limit wires are changed automatically. Dipswitch ON, gate closes to the right. Dipswitch OFF, gate closes to the left.

3. Auto close. (Dipswitch 3 ON). (Infra-red beams must be fitted if auto close is activated).

When Auto close is activated and the Gate opens to the open limit, the gate will wait the pre-programmed time before automatically closing. If the gate is triggered while the gate is in its closing cycle it will stop and reopen.

If the transmitter or manual push button is pressed while the gate is in its opening cycle, the gate will stop and close after the preprogrammed auto close time (from any position, not only from the open limit)

3a. Party mode. To override the auto close, wait till the gate reaches its open limit then press & hold the transmitter or manual push button for approximately 6 sec. (The control card will give 1 long beep to confirm the override) To reactivate the auto close, press the transmitter or manual push button.

4. Condominium/free exit loop (Dipswitch 4 ON)

When condominium/free exit loop is activated on the unit, the unit will not respond to any transmitter or manual push button while in its opening cycle or open position. When the gate is on the open limit the unit will automatically wait the pre-programmed auto close time and then close (even if auto close function is not selected i.e. dipswitch 3 is off). When the gate is in its closing cycle and the transmitter or manual push button is pressed the gate will stop and open. Auto close cannot be over ridden in condominium mode. (No party mode). If main power fails, the motor will still operate until battery reaches 9.5 volt. Gate will then remain open.

Change to manual by overriding the motor by the override lever. When the main power comes on again, lock in the override lever and the motor will function as normal.

5. **P.I.R.A.C (Passive Infra Red Access Control) (Dipswitch 5 On)**

With P.I.R.A.C mode activated, if the gate is its opening cycle and the IR beam is activated the gate will stop and close immediately after the IR beam is clear. This will happen even if auto close has not been selected.

(Be aware of this factor should a trailer be in tow!!!!)

6. **Slowdown (Dipswitch 6)**

With dipswitch selected ON, the gate will have a long close and open controlled slow down distance of 800mm and with the dipswitch OFF, the close and open controlled slow down distance will be 400mm.

NOTE – (800mm slow down distance is recommended if the limit is continuously being overrun). The 800mm distance can be reprogrammed (Between 200 & 1000mm) by selecting dipswitch 1 & 6 to the ON position. Push & hold the BT Set button, count the beeps, 1 beep equals 100mm. Release the BT Set button on the required distance, switch both dipswitches OFF then switch 6 back ON.

7. **Tamper Alarm Facility**

If the courtesy light feature is not used then the courtesy light relay can be re-configured as a general Tamper alarm output. Re-configuration is achieved with the following procedure.

A) **Three minute Latching tamper (Siren – N/O relay contact) output.**

Make note of the option dip switch settings, then remove the power (AC and DC) from the control PCB and open the gearbox release. Switch all dip switches to the OFF position, then select dipswitch 1 and 6 to the ON position. Reconnect the power to the PCB and after approximately 2 seconds, select dipswitch 1 and 6 back to OFF position.

The setting is confirmed by 1 to 5 beeps (depending on where the load pot setting is).

Select the dipswitch settings back as per your notes. Close the gearbox release and perform the normal power up calibration routine.

B) **Impulse tamper (Alarm – N/O relay contact) output.** Repeat section A) using dipswitch 1 and 5.

C) **Normal Courtesy light mode. (No Tamper alarm).** Repeat section A) using only dipswitch 1.

D) **Continuous alarm output.** Repeat section A) using dipswitch 1 and 4.


The tamper alarm will automatically arm itself when the gate is in the closed position and will trigger the alarm relay if the gate is moved or forced off the closed limit switch without a valid trigger.

If latching mode is configured, the relay will switch every 3 minutes until the alarm is restored.

If impulse mode is configured, the relay will trigger only once.

Any valid gate or pedestrian input trigger will cancel the tamper alarm which will automatically re-arm once the gate is again in the close position.

The alarm can also be disabled for maintenance by opening the gearbox release and pressing the remote control push button (confirmed by 3 short beeps). The alarm will remain disabled until the gearbox release is closed and the gate closed position re-confirmed.



8. **Anti-hijack**

When the tamper alarm function is active and the gate receives a valid trigger but is obstructed and cannot move or did not move more than 150mm, the alarm or siren will activate. If the beams are obstructed or blocked when a trigger is received, the gate will open but will then also sound the alarm.

9. **Holiday Lock-out facility** (This function must be programmed in).

(To program the above, follow the alarm function procedure but utilizing dipswitch 1, 5&6). To activate holiday lock-out, (the gate must be in the closed position) press and hold any pedestrian trigger function for a period of approximately 13 seconds. After approximately 13 seconds the PCB will give one three second beep as acknowledgement that holiday lock-out is now activated. To de-activate holiday lock-out, repeat the above process. The PCB will in this instance give five 1 second beeps as acknowledgement de-activate.


10. **Energy saving mode** (Only applicable on the SL100 PCB's)

N.B. If an external receiver is fitted, the power for this receiver must be connected directly to the battery connection and not to the 12V auxiliary output as the auxiliary power switches off when no AC (220V) or solar power is detected for 3 minutes. (Saving battery live) The PCB will rectify itself on a input trigger when in energy saving mode.

POWER CONNECTIONS

Low voltage (OBT) (25 VA) transformer – 220V at gate. (DTS500 has a 500m/Amp fuse)
(Connect also for 16VAC plug in transformer)


Connect 220V AC wires to input side of 500/16volt AC transformer (black & brown wires), or to the NEL (Neutral/Earth/ Live) connector on the side of transformer, then connect the 2 output wires (red) to 16VAC connectors on controller card.



DO NOT CONNECT 220V DIRECTLY TO PCB

Please note: When 220V is used at the gate motor, a separate double pole isolator must be fitted within 1 meter from the motor.

COURTESY LIGHT OUTPUT (Will stay on for 3 minutes after a trigger is received)




Please note that the Amps usage on the courtesy lights must not exceed 10Amps.
(If this facility is not being used, it can then be utilized as a tamper alarm facility, see page 9).

DO NOT CONNECT 220V DIRECTLY TO PCB UNDER ANY CIRCUMSTANCES.

DO ALL RUNTIME (Calibrating) AND TRANSMITTER PROGRAMMING BEFORE CONNECTING ANY ADDITIONAL INPUTS SUCH AS, – INTERCOM, EXTERNAL RECEIVERS, BEAMS, ETC.

Diagram to connect IR Beams to PCB



Important – Remove the fitted bridge by S/BEAM connected between CMN & N/C.

If no beams are fitted then a bridge must be fitted between CMN & N/C.

Note: If sentry beams are fitted, then S/BEAM, N/C on the PCB must be connected to N/O on the Beam

NOTE- IR beams must be fitted if auto-close is activated.

Dipswitch selections to activate a function.

Dipswitch 1 – Programming.

2 – Motor direction. (This can only be changed before programming or if neither limit switches are activated).

3 – Auto-close.

4 – Condominium mode.


5 – P.I.R.A.C. mode

6 – Slow down distance change

Dipswitch selection for programming. (With dipswitch 1 ON)

Dipswitch 3 – Auto-close. (Infra red beams must be fitted if auto close is activated).

Dipswitch 4 – Pedestrian (Open distance and auto close time).



DO NOT CONNECT 220V DIRECTLY TO PCB

PROGRAMMING

1 – Run Time (Calibrating) Setup (With total power up, AC and DC, on PCB)

- Unlock and open the override lever on the gearbox.



- Open the gate manually approximately 1metre.
- Close and lock the override lever on the gearbox. (PCB should beep 1-5 beeps pending on load pot setting)



- Pull the gate in any direction until the gear locks in.
- With all dipswitches OFF (excluding dipswitch 2 depending on motor direction), press & release the TEST/SET button.
- Gate will close, open and close again and stop on close limit. (Motor speed can be increased during programming cycle by pushing and holding down the TEST/SET button, but release the button approximately 500mm before the close and open position). The final closing cycle of programming will automatically run at normal speed.
- Control card will beep twice to confirm end of program run time (calibrating) setup.

NOTE: 1) If gate opens first, dipswitch number 2 is wrongly selected.
 2) Gate will automatically calibrate every time the power is restored after a total power failure, irrespective of present dipswitch selection.
 3) The controller will drive the gate approximately 6mm past the closed limit activation position. Allowance must be made for this when setting the limit actuators.

2 – Auto close (Default 10 seconds) (Infra red beams must be fitted if auto close is activated).

- Switch Dipswitch 1 and 3 on.
- Press & hold TEST/SET button.
- PCB will Beep (1 Beep = 1 Sec of auto close time) (Maximum 180 seconds).
- Release TEST/SET button at required auto close time.
- Switch Dipswitch 1 and 3 off.
- Switch Dipswitch 3 back on to activate the auto close.

3 – Pedestrian Opening (Default 1 meter / 10 seconds auto close)

- Switch Dipswitch 1 and 4 on.
- Gate must be in the closed position.
- Press & Release TEST/SET Button.
- Gate will open.
- Press & release TEST/SET button to stop gate at required pedestrian opening distance.
- Press & Hold TEST/SET button to program auto close time required.
- Control card will Beep (1 Beep = 1 Sec of auto close time) (Maximum 120 seconds).
- Release TEST/SET button at required pedestrian auto close time.
- Switch Dipswitch 1 and 4 off.
- Gate will close again.
- **Do not** switch dipswitch number 4 back on.

To reset factory defaults.

Remove all power from the PCB. Hold down the TEST/SET button and re-connect the AC power, with AC power now on, release TEST/SET button. PCB will give one 2 second long beep followed by 1-5 beeps, depending on load setting on pot, as acknowledgement.

Load setting

To adjust the load, turn the provided load pot to determine the load setting (Minimum, anticlockwise & Maximum, clockwise). The control card will beep, 1 minimum to 5 maximum beeps on next trigger before movement.




List of audio indications and warnings.

- One continuous beep - PCB is damage, replace PCB.
- One 1.5 second beep - “Party mode” has been activated.
- One 2 second beep - Factory defaults have been set.
- One 2 second beep - Beams are incorrectly wired or faulty when programming the motor.
or Runtime was aborted for whatever reason.
- One 3 second beep - Holiday lockout mode has been activated.
- One 3 second beep - Gate triggered when motor is in 3 minute overload lockout.
- Two 400 ms beeps - Run time programming (calibrating) has been successful.
- Two 1 second beeps - Pedestrian mode was activated.
or No AC power is present, running battery power only.
- Three 200ms beeps - Battery power is too low, or
Override function is open or faulty.
- Four 100ms beeps - Motor is in holiday lockout.
- Four 200ms beeps - Check motor/load fuse (25amp).
- Check motor brushes and armature.
- PCB reader not picking up Magnet on motor.
- Five 1 second beeps - Holiday lockout mode has been de-activated.
- Twenty 100ms beeps - Motor has stalled or overloaded, then check the following points:
 - 1) Gate pulling force (should not exceed 12.5kg)
 - 2) Load pot is set too low (Turn pot completely clockwise)
 - 3) Battery voltage under load (12volt) (Not connected)
 - 4) Gearbox gearwheel.

FOR SAFETY REASONS.

Infra red beams are recommended for
all gate motor installations.

PCB Control card. (Please note, can only connect a low voltage power supply and therefore cannot be modified as a High excess motor)



NB – When connecting intercoms to the control card (IT and CMN), please ensure that your intercom trigger output is potential free (**ZERO voltage**). If not, a gate relay module **must** be fitted.

Please ensure that the auxiliaries connected to the 12 volt auxiliary output does not exceed 500 m/Amps in total. (If so, remove from 12V auxiliary output and connect directly to battery)

TROUBLESHOOTING

SYMPTOMS	CAUSES	ACTION
When pressing the remote transmitter or manual push button the gate operator will not respond at all.	<p>Transmitter battery flat.</p> <p>Transmitter or manual push button is physically damaged.</p> <p>Transmitter has not been programmed into the receiver memory or manual push button is not connected to the PCB or push button.</p>	<p>Replace transmitter battery.</p> <p>Check with supplier.</p> <p>Follow the receiver setup instructions. Check wiring between PCB and push button.</p>
When pressing the remote transmitter the PCB gives 3 beeps and does not move but the 12v 7AH battery is OK.	The override reed switch in the gear box is faulty or failing to make connection between PCB and reed switch or the magnet in the override door is missing.	Replace the reed switch and or the magnet. (For short term solution, bridge out the two pins on the PCB where the reed switch wires should go).
PCB responds but gate will not open.	Condominium /loop option is not activated and the battery has reached its low level. (9.5Volt).	Check the household main supply, the transformer or Power Supply Unit and all related cabling.
PCB responds by giving 4 very quick 100ms beeps but will not open.	Motor is in holiday lockout.	Press and hold the pedestrian remote or manual push button connected to PT on PCB for approximately 13 seconds until PCB gives 5 long beeps.
PCB responds by giving 4 200ms beeps but no movement.	Motor/Load fuse is faulty, motor brushes not making contact with armature or battery is disconnected.	<p>Replace fuse.</p> <p>Repair or replace (if shorter than 7mm) motor brushes.</p> <p>Re-connect battery.</p>
Charge rate drops to +-7 volt.	12 Volt aux. output of 500m/Amps have been exceeded.	Remove some of the auxiliaries. (Can connect them to the battery directly)
Before operating, the unit gives two 2 beeps on opening but not on closing.	The primary supply has failed and the unit is running on battery reserve.	Check the household main supply, the AC transformer or DC Power Supply Unit and all related cabling.

<p>The unit gives two beeps and opens partially and stops, gives two beeps and then closes.</p> <p>Gate opens fast but closes slowly.</p>	<p>The pedestrian (PT) mode on the PCB is being triggered.</p> <p>A transmitter code has been programmed incorrectly into the pedestrian (PED) function of the receiver.</p> <p>Lost contact between release switch and PCB.</p> <p>Lost open limit connection after gate stopped on limit</p>	<p>Check equipment /cabling attached to the pedestrian (PT) on the PCB input.</p> <p>Delete the transmitter and re-program the transmitter into the receivers (GATE) as per instructions.</p> <p>Check contact between read switch and PCB (Green wire)</p> <p>Move actuator and or motor closer to each other.</p>
<p>When gate reaches a limit actuator, the unit does not stop running.</p>	<p>Limit input wired incorrectly (out of sync' with the motor direction.)</p> <p>Limit switch is faulty.</p>	<p>Re-wire</p> <p>Change limit switch or check with supplier.</p>
<p>Gate motor is jumping teeth on the rack.</p>	<p>Pinion to rack spacing is incorrect.</p> <p>Rack is insufficiently fastened to gate leaf.</p> <p>Debris on track</p>	<p>Re-align.</p> <p>Re-align and correct fastening.</p> <p>Clean track.</p>
<p>Gate jams in the open or closed position and is not easy to manually release.</p> <p>Gate opens pedestrian when full open trigger is given.</p> <p>PCB does not beep 1-5 beeps on closing the override lever.</p>	<p>Gate is running too far.</p> <p>Gate is running past its limit actuator.</p> <p>Gate is overloading in the close position after it received a pedestrian trigger.</p> <p>The magnet inside the override lever is missing.</p> <p>The double green wire reed switch inside the gearbox is faulty.</p>	<p>Adjust the limit actuators until there is a gap between gate and stoppers of approximately 10 – 15 mm</p> <p>Replace the switch, rewire correctly or check limit spring assembly.</p> <p>Move the closing limit actuator towards the closing cycle approximately 10mm.</p> <p>Replace the magnet.</p> <p>Replace the reed switch. (The reset pins on the PCB can be bridged as a short term solution).</p>

Manufacturers warranty.

- **All motors manufactured by DTS Security carry a 24 month factory warranty from date of invoice. (Excluding batteries & Remote controls).**
- **Batteries & remote controls carry a 12 months warranty.**
(Remote batteries are consumables and therefore carry NO warranty)
- **All goods are warranted to be free from faulty components and manufacture.**
- **Faulty goods will be repaired or replaced at the sole discretion of DTS Security Products, free of charge.**
- **This warranty is subject to the goods being returned to the premises of DTS Security Products.**
- **This warranty excludes lightening damage, insect damage and damage caused by faulty installation.**
- **In the event of the goods being supplied by dealer, merchant, agent or duly appointed installer of DTS Security Products, the claim must be directed to that supplier.**
- **The carriage of goods is for the customer's account.**
- **This warranty is only valid if the correct installation and application of goods, as laid out in the applicable documentation accompanying said goods, is adhered to.**
- **All warranty claims must be accompanied by the original invoice.**
- **The liability of DTS Security Products and / or their distributors is limited as herein set out. DTS Security Products and / or their distributors will not be liable for consequential, incident damage or injury howsoever arising.**